

Hind Terminals Nhava Sheva Tariff for Dry Units

Sr.	Location	Area	Type of Repair	DESCRIPTION OF REPAIRS	Repair Code	LABOUR HOUR RATE:				65.00
						M/Hrs	M/Hrs	MT/L	TOTAL COST	
1	ALL PANELS	Panel	Insert	Insert on panels 0 - 6 inches	PAN333NT10	0.75	48.75	121.50	170.25	
2	ALL PANELS	Panel	Insert	Insert on panels 7 to 12 inches	PAN333NT43	1.00	65.00	204.75	269.75	
3	ALL PANELS	Panel	Insert	Insert on panels 13 to 24 inches	PAN333NT76	1.50	97.50	290.13	395.63	
4	ALL PANELS	Panel	Insert	Insert on panels 24 x 24 inches	PAN333NT109	2.00	130.00	497.25	627.25	
5	ALL PANELS	Panel	Insert	Insert on panels 48 x 24 inches	PAN333NT42	3.00	195.00	714.38	909.38	
6	ALL PANELS	Panel	Insert	Insert on panels 48 x 48 inches	PAN333NT75	4.00	260.00	1,616.63	1,876.63	
7	ALL PANELS	Panel	Insert	Insert on panels 36 x 12 inches	PAN333NT108	2.00	130.00	372.50	502.50	
8	ALL PANELS	Panel	Insert	Insert on panels 96 x 36 inches	PAN333NT141	4.50	292.50	2,416.25	2,708.75	
9	ALL PANELS	Panel	Insert	Insert on panels 36 x 24 inches	PAN333NT174	3.00	195.00	605.00	800.00	
10	ALL PANELS	Panel	Insert	Insert on panels 48 x 36 inches	PAN333NT107	3.50	227.50	1,212.19	1,439.69	
11	ALL PANELS	Panel	Insert	Insert on panels 36 x 36 inches	PAN333NT40	3.50	227.50	864.38	1,091.88	
12	ALL PANELS	Panel	Insert	Patch/Insert above 10 ft. Every additional sq. ft.	PAN333NT73	0.50	32.50	155.25	187.75	
13	ALL PANELS	Panel	Straighen	Straighen on panels 0 - 6 inches	PAN333STN106	0.25	16.25	13.50	29.75	
14	ALL PANELS	Panel	Straighen	Straighen on panels 7 to 12 inches	PAN333STN89	0.50	32.50	23.63	56.13	
15	ALL PANELS	Panel	Straighen	Straighen on panels 13 to 24 inches	PAN333STN72	1.00	65.00	27.00	92.00	
16	ALL PANELS	Panel	Straighen	Straighen on panels 24 x 24 inches	PAN333STN105	1.50	97.50	61.88	159.38	
17	ALL PANELS	Panel	Straighen	Straighen on panels 48 x 24 inches	PAN333STN88	2.50	162.50	61.00	243.50	
18	ALL PANELS	Panel	Straighen	Straighen on panels 48 x 48 inches	PAN333STN71	3.75	243.75	99.00	342.75	
19	ALL PANELS	Panel	Straighen	Straighen on panels 96 x 48 inches	PAN333STN104	5.00	325.00		325.00	
20	ALL PANELS	Panel	Straighen	Straighen on panels 48 x 36 inches	PAN333STN47	3.00	195.00	90.00	285.00	
21	ALL PANELS	Panel	Straighen	Straighen on panels 72 x 36 inches	PAN333STN70	4.00	260.00	103.75	363.75	
22	ALL PANELS	Panel	Straighen	Straighen on panels 60 x 48 inches	PAN333STN103	4.00	260.00	107.50	367.50	
23	ALL PANELS	Panel	Straighen	Straighen on panels 72 x 48 inches	PAN333STN86	4.50	292.50	117.50	410.00	
24	ALL PANELS	Panel	Straighen	Straighen on panels 36 x 24 inches	PAN333STN69	2.00	130.00	71.44	201.44	
25	ALL PANELS	Panel	Straighen	Straighen on panels 96 x 48 inches	PAN333STN102	4.50	292.50	127.50	420.00	
26	ALL PANELS	Panel	Straighen	Straighen on panels 36 x 36 inches	PAN333STN25	2.50	162.50	85.00	247.50	
27	BOTTOM - FRONT, REAR RAIL	Rail	Straighen and Weld	Straighen and weld bottom side, front, rear rail(s) 6 inches	BHE33STO36	0.50	32.50	49.73	82.23	
28	BOTTOM - FRONT, REAR RAIL	Rail	Straighen and Weld	Straighen and weld gusset each (interior/exterior) bottom rails.	BHE33STO69	0.50	32.50	43.88	76.38	
29	BOTTOM - FRONT, REAR RAIL	Rail Header	Straighen	Straighen rail(s) 0 - 6 inches	BHE733STN102	0.75	48.75	31.50	80.25	
30	BOTTOM - FRONT, REAR RAIL	Rail Header	Straighen	Straighen rail(s) 7 to 12 inches	BHE733STN85	1.00	65.00	61.88	126.88	
31	BOTTOM - FRONT, REAR RAIL	Rail Header	Straighen	Straighen rail(s) 13 to 24 inches	BHE733STN68	1.25	81.25	186.75	268.00	
32	BOTTOM - FRONT, REAR RAIL	Rail Header	Straighen	Straighen rail(s) 25 x 48 inches	BHE733STN101	2.00	130.00	211.50	341.50	
33	BOTTOM - FRONT, REAR RAIL	Rail Header	Straighen	Straighen rail(s) Every additional foot	BHE733STN64	0.25	16.25	24.75	41.00	
34	BOTTOM - FRONT, REAR RAIL	Rail Header	Straighen and Weld	Straighen and weld bottom side, front, rear/rail every additional 6 inches.	BHE733STO67	0.25	16.25	37.29	53.54	
35	BOTTOM RAIL	Rail	Insert	Insert (partial profile) bottom side rail full 20 ft.	BRA633NT144	10.00	650.00	2,237.63	2,887.63	
36	BOTTOM RAIL	Rail	Insert	Insert (partial profile) bottom front rail full 8 ft.	BRA633NT77	4.50	292.50	1,119.38	1,411.88	
37	BOTTOM RAIL	Rail	Insert	Insert (partial profile) bottom rear rail full 8 ft.	BRA633NT110	6.00	390.00	1,181.25	1,571.25	
38	BOTTOM RAIL	Rail	Insert	Insert (partial profile) bottom side, front & rear rail first foot	BRA633NT43	1.50	97.50	209.25	306.75	
39	BOTTOM RAIL	Rail	Insert	Insert (partial profile) bottom side, rear rail every additional foot.	BRA633NT76	0.75	48.75	199.13	247.88	
40	BOTTOM RAIL	Rail	Replace	Replace (full profile) bottom side rail with components 20 ft.	BRA633REP109	17.00	1,105.00	3,357.50	4,462.50	
41	BOTTOM RAIL	Rail	Replace	Replace (full profile) bottom side rail with components 40 ft.	BRA633REP42	25.00	1,625.00	7,335.00	8,960.00	
42	BOTTOM RAIL	Rail	Replace	Replace (full profile) bottom front rail with components 6 ft.	BRA633REP75	6.00	390.00	2,100.38	2,490.38	
43	BOTTOM RAIL	Rail	Replace	Replace (full profile) bottom rear rail(s) with components 8 ft.	BRA633REP108	7.50	487.50	1,802.53	2,290.03	
44	BOTTOM RAIL	Rail	Replace	Replace gusset each (interior/exterior) bottom rails)	BRA633REP41	0.75	48.75	66.63	117.38	
45	BOTTOM RAIL	Rail	Section	Section (full profile) bottom side rail first foot.	BRA633SEN474	2.00	130.00	360.00	490.00	
46	BOTTOM RAIL	Rail	Section	Section (full profile) bottom side rail every additional foot	BRA633SEN107	1.50	97.50	335.81	433.31	
47	BOTTOM RAIL	Rail	Section	Section (full profile) bottom front rail first foot.	BRA633SEN440	2.00	130.00	366.75	496.75	
48	BOTTOM RAIL	Rail	Section	Section (full profile) bottom rear rail every additional foot	BRA633SEN473	1.50	97.50	364.38	461.88	
49	BOTTOM RAIL	Rail	Section	Section (full profile) bottom rear rail(s) first foot.	BRA633SEN106	2.00	130.00	366.75	496.75	
50	BOTTOM RAIL	Rail	Section	Section (full profile) bottom rear(s) every additional foot	BRA633SEN109	1.50	97.50	364.38	461.88	
51	BOWS AND TIR CORD	Rof bows	Replace	Replace bow each	OPE144RPN0	0.50	32.50	432.00	464.50	
52	BOWS AND TIR CORD	TIR Cord	Replace	Replace T.I.R. cord 20 ft.	OPE255REP104	0.75	48.75	714.38	763.13	
53	BOWS AND TIR CORD	TIR Cord	Replace	Replace T.I.R. cord 40 ft.	OPE255REP99	1.25	81.25	1,243.13	1,324.38	
54	BOWS AND TIR CORD	TIR Cord	Replace	Replace T.I.R. cord end PC/canal.	OPE255REP114	0.50	32.50	51.75	64.25	
55	CORNER POST	Corner casting	Re-Align	Corner casting ... re-alignment each	COR311REN64	2.00	130.00	148.75	278.75	
56	CORNER POST	Corner casting	Replace	Replace corner casting each (up/bottom) (del/ring)	COR311REP75	3.00	195.00	1,181.25	1,376.25	
57	CORNER POST	Corner Post	Insert	Insert (partial profile) front corner post full length.	COR311INT86	8.00	520.00	2,424.38	2,944.38	
58	CORNER POST	Corner Post	Insert	Insert (partial profile) front corner post first foot.	COR311INT97	2.00	130.00	398.25	528.25	
59	CORNER POST	Corner Post	Insert	Insert (partial profile) front corner post every additional foot	COR311INT108	1.50	97.50	373.50	471.00	
60	CORNER POST	Corner Post	Insert	Insert (partial profile) rear corner post first foot.	COR311INT19	2.00	130.00	509.63	639.63	
61	CORNER POST	Corner Post	Insert	Insert (partial profile) rear corner post every additional foot	COR311INT30	1.50	97.50	497.25	594.75	
62	CORNER POST	Corner Post	Insert	Insert rear corner post "J" bar first foot.	COR311INT41	1.00	65.00	105.75	170.75	
63	CORNER POST	Corner Post	Insert	Insert rear corner post "J" bar every additional foot.	COR311INT52	1.00	65.00	97.88	162.88	
64	CORNER POST	Corner Post	Re-Align	Realign front/rear corner post each.	COR311REN63	2.00	130.00	248.63	378.63	
65	CORNER POST	Corner Post	Replace	Replace front corner post complete w/o casting (universal type).	COR311REP74	12.00	780.00	5,531.63	6,311.63	
66	CORNER POST	Corner Post	Replace	Replace rear corner post complete w/o casting [universal type]	COR311REP76	13.00	845.00	6,030.00	6,875.00	
67	CORNER POST	Corner Post	Straighen	Straighen front/rear corner post first foot.	COR311STN66	0.75	48.75	59.63	108.38	
68	CORNER POST	Corner Post	Straighen	Straighen front/rear corner post every additional foot.	COR311STN07	0.50	32.50	49.73	82.23	
69	CORNER POST	Corner Post	Straighen and Weld	Straighen and weld front/rear corner post first 6 inches	COR311STO18	0.50	32.50	49.73	82.23	
70	CORNER POST	Corner Post	Straighen and Weld	Straighen and weld front/rear corner post every additional foot.	COR311STO29	0.25	16.25	37.13	53.38	
71	CORNER POST	Corner Post HC	Replace	Replace front corner post complete w/o casting (High Cube)	COR311REP40	12.00	780.00	7,152.50	7,932.50	
72	CORNER POST	Corner Post HC	Replace	Replace rear corner post complete w/o casting (High Cube)	COR311REP117	13.00	845.00	12,238.75	13,083.75	
73	CORNER POST	J Bar	Straighen	Straighen "J" bar first foot.	COR313STN64	0.50	32.50	49.73	82.23	
74	CORNER POST	Twist Lock	Straighen	Straighen "J" bar additional foot.	COR313STN127	0.25	16.25	43.88	60.13	
75	CORNER POST	Twist Lock	Remove and Refix	Twist Lock Remove & refix	COR313REN40	1.50	97.50	375.00	472.50	
76	CORNER POST	Twist Lock	Replace	Twist Lock replace	COR313REP106	1.00	65.00	2,250.00	2,315.00	
77	DOOR	Cargo label plate	Remove and Refix	Removal and reinstal cargo label plate.	DOO311REN46	0.50	32.50	49.50	82.00	
78	DOOR	Cargo label plate	Replace	Replace stainless steel cargo label plate.	DOO311REP97	0.50	32.50	155.25	187.75	
79	DOOR	Cargo label plate	Straighen	Straighen / Resecure cargo label plate.	DOO311STN108	0.25	16.25	31.50	47.75	
80	DOOR	Door	Re-Align	Re-align door each.	DOO311REN19	2.00	130.00	248.63	378.63	
81	DOOR	Extension plate	Insert	Insert top front/rear header extension plate every additional foot	DOO311INT30	1.00	65.00	228.75	293.75	
82	DOOR	Frames	Insert	DOOR FRAME VERTICAL & HORIZONTAL INSERT 1 Ft.	DOO777NT41	1.00	65.00	93.38	158.38	
83	DOOR	Frames	Insert	DOOR FRAME VERTICAL & HORIZONTAL INSERT every additional Ft.	DOO777NT118	1.00	65.00	86.63	151.63	
84	DOOR	Frames	Replace	DOOR FRAME VERTICAL & HORIZONTAL REPLACE	DOO777REN45	5.00	325.00	1,120.00	1,445.00	
85	DOOR	Frames	Section	DOOR FRAME VERTICAL & HORIZONTAL Section 1 Ft.	DOO777SEN19	1.50	97.50	310.50	408.00	
86	DOOR	Frames	Section	DOOR FRAME VERTICAL & HORIZONTAL Section every additional Ft.	DOO777SEN49	0.50	32.50	248.63	281.13	
87	DOOR	Frames	Straighen	DOOR FRAME VERTICAL & HORIZONTAL Straighen 0 - 6 inches	DOO777STN126	0.50	32.50	31.16	63.66	
88	DOOR	Frames	Straighen	DOOR FRAME VERTICAL & HORIZONTAL Straighen 7 to 12 inches	DOO777STN103	0.75	48.75	37.29	86.04	
89	DOOR	Frames	Straighen	DOOR FRAME VERTICAL & HORIZONTAL Straighen 13 to 24 inches	DOO777STN80	1.25	81.25	74.59	156.84	
90	DOOR	Frames	Straighen	DOOR FRAME VERTICAL & HORIZONTAL Straighen 25 x 48 inches	DOO777STN157	1.50	97.50	105.75	203.25	
91	DOOR	Frames	Straighen	DOOR FRAME VERTICAL & HORIZONTAL Straighen Every additional foot	DOO777STN134	0.25	16.25	24.75	41.00	
92	DOOR	GASKET/SEAL & RETAINER STRIP	Replace	Replace complete gasket/seal including retainer strip 24 ft & of one door.	DOO322REP111	5.00	325.00	1,802.25	2,127.25	
93	DOOR	GASKET/SEAL & RETAINER STRIP	Replace	Replace complete retainer strip 24 ft.	DOO322REP93	3.00	195.00	110.25	305.25	
94	DOOR	GASKET/SEAL & RETAINER STRIP	Section	Section gasket/seal upto 4 ft including retainer strip and corner tabs.	DOO322SEN65	1.00	65.00	201.25	266.25	
95	DOOR	GASKET/SEAL & RETAINER STRIP	Section	Section gasket/seal upto 1 ft including retainer strip and corner tabs	DOO322SEN77	0.50	32.50	93.38	125.88	
96	DOOR	GASKET/SEAL & RETAINER STRIP	Section	Section retainer strip upto 4 ft.	DOO322SEN99	0.50	32.50	31.50	64.00	
97	DOOR	GASKET/SEAL & RETAINER STRIP	Section	Section retainer strip 1 ft.	DOO322SEN121	0.25	16.25	12.38	28.63	
98	DOOR	GASKET/SEAL & RETAINER STRIP	Straighen	Straighen and resecure / fasten 4' retainer strip with gasket.	DOO322STN43	0.75	48.75	22.50	71.25	
99	DOOR	GASKET/SEAL & RETAINER STRIP	Straighen	Straighen and resecure / fasten every additional 1 ft. retainer strip with gasket.	DOO322STN65	0.20	13.00	9.00	22.00	
100	DOOR	Handle	Free-up	Free-up door handle/catch/retainer each.	DOO622FRP67	0.10	6.50	12.38	18.88	
101	DOOR	Handle	Replace	Replace door handle each.	DOO622REP109	0.50	32.50	248.63	281.13	
102	DOOR	Handle	Replace	Replace door handle each (hub) each.	DOO622REP103	0.50	32.50	111.38	143.88	
103	DOOR	Handle	Replace	Replace door handle retainer each.	DOO622REP93	0.50	32.50	61.88	94.38	
104	DOOR	Handle	Replace	Replace retainer catch.	DOO622REP75	0.25	16.25	24.75	41.00	
105	DOOR	Handle	Straighen	Straighen door handle each.	DOO622STN67	0.50	32.50	37.13	69.63	
106	DOOR	Handle	Straighen	Straighen door handle (hub) each	DOO622STN119	0.25	16.25	24.75	41.00	
107	DOOR	Handle	Straighen	Straighen door handle retainer each.	DOO622STN41	0.10	6.50	12.38	18.88	
108	DOOR	Handle	Remove/Straighen and refix handle each.	DOO622STN63	0.75	48.75	43.88	92.63		
109	DOOR	HINGE/LUG/GRN	Free-up	Free-Up 4 hinges (per door)	DOO622FRP65	0.50	32.50	24.75	57.25	
110	DOOR	HINGE/LUG/GRN	Replace	Replace complete assembly (hinge blade lug & pin)	DOO622REP107	2.00	130.00	155.25	285.25	
111	DOOR	HINGE/LUG/GRN	Replace	Replace hinge blade each only.	DOO622REP29	1.50	97.50			

Hind Terminals Nhava Sheva Tariff for Dry Units

Sr.	Location	Area	Type of Repair	DESCRIPTION OF REPAIRS	Repair Code	LABOUR HOUR RATE:				65.00
						M/Hrs	M/Hrs	MTL	TOTAL COST	
178	FLOOR	Threshold plate	Straighten	Straighten threshold plate.	FLO358TN03	0.25	16.25	24.75	41.00	
179	FLOOR	Threshold plate	Straighten	Remove/wagren & refix threshold plate.	FLO358TN68	2.00	130.00	204.75	334.75	
180	FLOOR & PANEL	Floor board	Cleaning	Chemicalsteam wash complete inside ... 20 ft	FLP913CLG09			225.00	225.00	
181	FLOOR & PANEL	Floor board	Cleaning	Chemicalsteam wash complete inside ... 40 ft	FLP913CLG100			437.50	437.50	
182	FLOOR & PANEL	Panel	Cleaning	Normal wash with complete inside panel 20 ft.	FLP333CLG11			112.50	112.50	
183	FLOOR & PANEL	Panel	Cleaning	Normal wash with complete inside panel 40 ft.	FLP333CLG44			175.00	175.00	
184	GENERAL & MISCELLANEOUS	Corner Post	Replace	Replace/Ref cement front corner post corner cover each	GEN311REP193	0.50	32.50	19.13	51.63	
185	GENERAL & MISCELLANEOUS	CSC plate	Replace	Replace C.S.C. plate.	GEN311REP104	0.50	32.50	155.25	187.75	
186	GENERAL & MISCELLANEOUS	CSC plate	Update	Update C.S.C. plate details.	GEN311LEP15			29.25	29.25	
187	GENERAL & MISCELLANEOUS	Door	Replace	BOLTNUTS REPLACE (FASTNERS) EACH	GEN311REP26			18.75	18.75	
188	GENERAL & MISCELLANEOUS	Door Tie-back	Replace	Replace door tie-back each.	GEN11LEP77	0.25	16.25	20.25	36.50	
189	GENERAL & MISCELLANEOUS	Flare board	Cleaning	Tar spray/Remove 1 sq. ft.	GEN333CLG46			25.00	25.00	
190	GENERAL & MISCELLANEOUS	Gasket	Patch	Patch / joint gaskets.	GEN232PAH69	0.25	16.25	14.63	30.88	
191	GENERAL & MISCELLANEOUS	General	Refix	Resecure/Refix data plate each.	GEN422REX81	0.10	6.50	18.00	24.50	
192	GENERAL & MISCELLANEOUS	General	Remove	Remove stickers each.	GEN422REE103			3.75	3.75	
193	GENERAL & MISCELLANEOUS	General	Remove	Cut away any lashing attachments/grind.	GEN422REE25			19.13	19.13	
194	GENERAL & MISCELLANEOUS	General	Remove	Remove/cut away rainwater complete.	GEN422REE47	1.00	65.00	73.13	138.13	
195	GENERAL & MISCELLANEOUS	General	Remove and Refix	Remove/Repair graffiti 1 sq. ft.	GEN422REM69			6.25	6.25	
196	GENERAL & MISCELLANEOUS	General	Repair	Repair door logo (small)	GEN422RET91			19.13	19.13	
197	GENERAL & MISCELLANEOUS	General	Repaint	Repaint large logo (per letter)	GEN422RET113			25.00	25.00	
198	GENERAL & MISCELLANEOUS	General	Repaint	Repaint/Remove each number/letter.	GEN422RET65			10.00	10.00	
199	GENERAL & MISCELLANEOUS	General	Replace	Replace cargo lashing ringbar each.	GEN422REP97	0.25	16.25	19.13	35.38	
200	GENERAL & MISCELLANEOUS	General	Straighten	Straighten tie-back each.	GEN422STN79	0.10	6.50	9.00	15.50	
201	GENERAL & MISCELLANEOUS	General	Straighten	Straighten data plate each.	GEN422STN01	0.10	6.50	9.00	15.50	
202	GENERAL & MISCELLANEOUS	General	Straighten	Straighten cargo lashing ringbar each.	GEN422STN23	0.10	6.50	10.24	16.74	
203	GENERAL & MISCELLANEOUS	General	Straighten	All flanges straighten first foot.	GEN422STN45	0.25	16.25	29.25	45.50	
204	GENERAL & MISCELLANEOUS	General	Straighten	All flanges straighten every additional foot.	GEN422STN67	0.20	13.00	29.25	42.25	
205	GENERAL & MISCELLANEOUS	General	Straighten	Straighten ranguter every 1 foot.	GEN422STN89	0.15	9.75	29.25	39.00	
206	GENERAL & MISCELLANEOUS	General	Straighten and Weld	Straighten and weld cargo lashing ringbar each.	GEN422STD111	0.25	16.25	12.50	28.75	
207	GENERAL & MISCELLANEOUS	General	Straighten and Weld	All flanges straighten and weld first foot.	GEN422STD303	0.50	32.50	43.88	76.38	
208	GENERAL & MISCELLANEOUS	General	Straighten and Weld	Straighten and weld ranguter first 6'	GEN422STD56	0.50	32.50	29.25	61.75	
209	GENERAL & MISCELLANEOUS	General	Straighten and Weld	Straighten and weld ranguter every additional 6'.	GEN422STD77	0.25	16.25	21.94	38.19	
210	GENERAL & MISCELLANEOUS	General	Welding	Weld only cargo lashing ringbar each.	GEN422WEG99	0.15	9.75	10.24	19.99	
211	GENERAL & MISCELLANEOUS	General	Welding	Weld door tie back each.	GEN422WEG121	0.15	9.75	10.24	19.99	
212	GENERAL & MISCELLANEOUS	Panel	Paint Touch-up	Paint Touch-Up 1 Sq. Ft	GEN333PAF43			10.00	10.00	
213	GENERAL & MISCELLANEOUS	Panel	Refurbishment	Refurbishment SPP	GEN333REF76			20,812.50	20,812.50	
214	GENERAL & MISCELLANEOUS	Panel	Repair	Repair complete weight panel.	GEN333RET109	1.50	97.50	49.50	147.00	
215	GENERAL & MISCELLANEOUS	Panel	SPP	Scrap, prime and paint per 1 sq. ft.	GEN333SPH42			32.50	32.50	
216	GENERAL & MISCELLANEOUS	Panel	Straighten	Straighten complete roof panels 20 ft	GEN333STN75	8.00	520.00	266.75	886.75	
217	GENERAL & MISCELLANEOUS	Panel	Straighten	Straighten complete roof corrugated panels 40 ft.	GEN333STN08	12.00	780.00	465.75	1,245.75	
218	GENERAL & MISCELLANEOUS	Panel	Welding	All pinholes anywhere on the container upto a total of first 6 nos.	GEN333WEG41	0.50	32.50	29.25	61.75	
219	GENERAL & MISCELLANEOUS	Panel	Welding	All pinholes anywhere on the container for an additional 6 nos.	GEN333WEG74	0.25	16.25	21.94	38.19	
220	GENERAL & MISCELLANEOUS	Stop plate	Replace	Replace door stop plate each.	GEN344REP107	0.75	48.75	33.75	82.50	
221	GENERAL & MISCELLANEOUS	Stop plate	Straighten	Remove, Straighten & refix door stop plate.	GEN344STN61	0.75	48.75	21.94	70.69	
222	GENERAL & MISCELLANEOUS	Stop plate	Straighten	Straighten door stop plate each.	GEN344STN65	0.25	16.25	12.38	28.63	
223	GENERAL & MISCELLANEOUS	Stop plate	Welding	Weld door stop plate each.	GEN344WEG139	0.25	16.25	12.50	28.75	
224	GENERAL & MISCELLANEOUS	TCT plate	Replace	Replace TCT plate.	GEN344REP93	0.25	16.25	111.38	127.63	
225	GENERAL & MISCELLANEOUS	Tie plate	Replace	Replace/Tie tie plate.	GEN355REP17	0.50	32.50	155.25	197.75	
226	PANEL (SIDE & FRONT)	Panel	Replace	Replace side wall complete... 20 ft (5 pcs)	PAN333REP26	18.00	1,170.00	13,096.00	14,866.00	
227	PANEL (SIDE & FRONT)	Panel	Replace	Replace side wall complete... 40 ft (10 pcs)	PAN333REP98	32.00	2,080.00	28,913.38	28,993.38	
228	PANEL (SIDE & FRONT)	Panel	Replace	Replace front side wall complete... (2 pcs)	PAN333REP101	8.00	520.00	6,265.13	6,785.13	
229	PANEL (SIDE & FRONT)	Panel	Replace	Replace one side wall panel... 8 ft x 4 ft	PAN333REP34	5.00	325.00	3,120.75	3,445.75	
230	PANEL (SIDE & FRONT)	Panel	Replace	Replace front side wall panel... 8 ft x 4 ft.	PAN333REP67	6.00	390.00	3,505.50	3,895.50	
231	PANEL (SIDE & FRONT)	Panel	Replace	Replace/Block inner ventilator panel.	PAN333REP100	1.50	97.50	167.63	265.13	
232	PANEL (SIDE & FRONT)	Panel	Replace	Replace inner vent. cover panel.	PAN333REP33	3.00	195.00	334.13	529.13	
233	PANEL (SIDE & FRONT)	Panel	Straighten and Weld	Straighten and weld panel first 6 inches.	PAN333STD66	0.50	32.50	49.50	82.00	
234	PANEL (SIDE & FRONT)	Panel	Straighten and Weld	Straighten and weld panel every additional 6 inches.	PAN333STD99	0.25	16.25	17.13	33.38	
235	PANEL (SIDE & FRONT)	Vent	Replace	Replace steel ventilator with components.	PAN666REP132	3.00	195.00	334.13	529.13	
236	PANEL (SIDE & FRONT)	Vent	Replace	Replace steel vent. cover only with components.	PAN666REP98	1.00	65.00	223.88	288.88	
237	PANEL (SIDE & FRONT)	Vent	Replace	Replace small vent.	PAN666REP164	0.50	32.50	105.75	138.25	
238	ROOF	Panel	Replace	Replace corrugated roof panel 20 ft (5 pcs)	ROC333REP247	18.00	1,170.00	11,934.00	13,104.00	
239	ROOF	Panel	Replace	Replace corrugated roof panel 40 ft (10 pcs)	ROC333REP80	30.00	1,950.00	23,619.38	25,569.38	
240	ROOF	Panel	Replace	Replace flat roof panel 20 ft (10 pcs)	ROC333REP113	20.00	1,300.00	11,188.13	12,488.13	
241	ROOF	Panel	Replace	Replace flat roof panel 40 ft	ROC333REP46	32.00	2,080.00	22,984.88	25,064.88	
242	ROOF	Panel	Replace	Replace roof panel with bows (hat type) 20 ft.	ROC333REP79	25.00	1,625.00	15,539.63	17,164.63	
243	ROOF	Panel	Replace	Replace roof panel with bows (hat type) 40 ft.	ROC333REP112	37.00	2,405.00	28,351.88	30,756.88	
244	ROOF	Panel	Replace	Replace roof panel with bows (box type) 20 ft.	ROC333REP45	25.00	1,625.00	15,471.13	17,096.13	
245	ROOF	Panel	Replace	Replace roof panel with bows (box type) 40 ft.	ROC333REP78	37.00	2,405.00	30,063.63	32,468.63	
246	ROOF	Panel	Replace	Replace one flat roof panel... 8 ft x 4 ft.)	ROC333REP111	6.00	390.00	2,803.13	3,193.13	
247	ROOF	Panel	Replace	Replace one corrugated roof panel... 8 ft x 4 ft	ROC333REP44	6.00	390.00	3,854.25	4,244.25	
248	ROOF	Panel	Straighten and Weld	Straighten and weld panel first 6'	ROC333STD77	0.50	32.50	50.63	83.13	
249	ROOF	Panel	Straighten and Weld	Straighten and weld panel every additional 6 inches	ROC333STD110	0.20	13.00	39.38	52.38	
250	ROOF	Protection plate	Straighten	Straighten corner protection plate/gusset each	ROC333STN43	0.50	32.50	37.13	69.63	
251	ROOF	Protection plate	Straighten and Weld	Straighten and weld corner protection plate or gusset each.	ROC333STD76	0.30	19.50	51.75	71.25	
252	ROOF	Roof bows	Replace	Replace roof bows (hat type) each	ROC344REP109	0.75	48.75	360.75	409.75	
253	ROOF	Roof bows	Replace	Replace roof bows (box type) each	ROC344REP93	0.75	48.75	453.38	502.13	
254	ROOF	Roof bows	Replace	Replace roof bows (hat type) every additional	ROC344REP97	0.75	48.75	402.19	450.94	
255	ROOF	Roof bows	Replace	Replace roof bows (box type) every additional	ROC344REP141	0.75	48.75	438.75	487.50	
256	ROOF	Roof bows	Replace	Replace corner protection plate/roof gusset each	ROC344REP85	1.50	97.50	123.75	221.25	
257	ROOF	Roof bows	Straighten	Straighten roof bow each	ROC344STN129	0.25	16.25	32.63	48.88	
258	ROOF	Roof bows	Straighten	Straighten roof bow every additional	ROC344STN73	0.25	16.25	27.00	43.25	
259	ROOF	Roof bows	Straighten	Remove straighten & refix roof bow each	ROC344STN117	0.50	32.50	43.88	76.38	
260	TARPAULINE	Tarpauline	Patch	Patch tarpaulin 6' x 6'	TAR544PAH09	0.50	32.50	49.50	82.00	
261	TARPAULINE	Tarpauline	Patch	Patch tarpaulin 12' x 12'	TAR544PAH13	0.75	48.75	111.38	160.13	
262	TARPAULINE	Tarpauline	Patch	Patch tarpaulin 4 sq ft	TAR544PAH67	2.00	130.00	273.50	503.50	
263	TARPAULINE	Tarpauline	Patch	Patch tarpaulin 8 sq ft	TAR544PAH01	3.00	195.00	622.13	817.13	
264	TARPAULINE	Tarpauline	Patch	Patch tarpaulin 16 sq ft	TAR544PAH45	4.00	260.00	670.75	1,130.75	
265	TARPAULINE	Tarpauline	Patch	Patch tarpaulin 32 sq ft	TAR544PAH69	5.00	325.00	1,368.00	1,693.00	
266	TARPAULINE	Tarpauline	Remove and Refix	Remove and Refix tarpaulin only 20 ft.	TAR544REM133			86.63	86.63	
267	TARPAULINE	Tarpauline	Remove and Refix	Remove and Refix tarpaulin only 40 ft.	TAR544REM77			118.13	118.13	
268	TARPAULINE	Tarpauline	Replace	Replace tarpaulin 20 ft (pvc fire retardant)	TAR544REP121	1.50	97.50	7,458.75	7,556.25	
269	TARPAULINE	Tarpauline	Replace	Replace tarpaulin 20 ft (Canvas)	TAR544REP65	1.50	97.50	2,178.00	2,275.50	
270	TARPAULINE	Tarpauline	Replace	Replace tarpaulin 40 ft (pvc fire retardant)	TAR544REP109	2.50	162.50	14,067.00	14,769.50	
271	TARPAULINE	Tarpauline	Replace	Replace tarpaulin 40 ft (Canvas)	TAR544REP63	2.50	162.50	4,459.50	4,622.00	
272	TARPAULINE	Tarpauline	Replace	Replace eyekit each.	TAR544REP97	0.25	16.25	24.75	41.00	
273	TOP - FRONT, SIDE, REAR RAIL HEADER	Rail	Straighten and Weld	Straighten and weld top side, front, rear rail 6 inches.	THE633STD282	0.75	48.75	47.25	96.00	
274	TOP - FRONT, SIDE, REAR RAIL HEADER	Rail	Straighten and Weld	Straighten and weld top side, front, rear rail add. 6 inches	THE633STD115	0.25	16.25	37.13	53.38	
275	TOP - FRONT, SIDE, REAR RAIL HEADER	Rail	Straighten and Weld	Straighten and weld gusset each (interior top rail)	THE633STD48	0.15	9.75	24.75	34.50	
276	TOP - FRONT, SIDE, REAR RAIL HEADER	Rail Header	Straighten	Straighten rail header 0 - 6 inches	THE733TN81	0.50	32.50	31.16	63.66	
277	TOP - FRONT, SIDE, REAR RAIL HEADER	Rail Header	Straighten	Straighten rail header 7 to 12 inches	THE733TN114	0.75	48.75	37.29	86.04	
278	TOP - FRONT, SIDE, REAR RAIL HEADER	Rail Header	Straighten	Straighten rail header 13 to 24 inches	THE733TN47	1.25	81.25	74.59	155.84	
279	TOP - FRONT, SIDE, REAR RAIL HEADER	Rail Header	Straighten	Straighten rail header 25 x 48 inches	THE733TN40	1.50	97.50	105.75	203.25	
280	TOP - FRONT, SIDE, REAR RAIL HEADER	Rail Header	Straighten	Straighten rail header Every additional foot	THE733TN113	0.25	16.25	24.75	41.00	
281	TOP - FRONT, SIDE, REAR RAIL HEADER FOR OPEN TC	Rail	Straighten	Straighten top rail 20 ft.	THE633STN09	8.00	520.00	1,119.38	1,639.38	
282	TOP - FRONT, SIDE, REAR RAIL HEADER FOR OPEN TC	Rail Header	Straighten	Straighten Rails 0 - 6 inches	THO733TN123	0.75	48.75	56.25	105.00	
283	TOP - FRONT, SIDE, REAR RAIL HEADER FOR OPEN TC	Rail Header	Straighten	Straighten Rails 7 to 12 inches	THO733TN66	1.00	65.00	68.63	133.63	
284	TOP - FRONT, SIDE, REAR RAIL HEADER FOR OPEN TC	Rail Header	Straighten	Straighten Rails 13 to 24 inches	THO733TN89	1.25	81.25	137.25	218.50	
285	TOP - FRONT, SIDE, REAR RAIL HEADER FOR OPEN TC	Rail Header	Straighten	Straighten Rails 25 x 48 inches	THO733TN122	2.00	130.00	283.50	413.50	
286	TOP - FRONT, SIDE, REAR RAIL HEADER FOR OPEN TC	Rail Header	Straighten	Straighten Rails Every additional foot	THO733TN65	0.50	32.50	61.88	94.38	
287	TOP RAIL	Extension plate	Insert	Insert top front/rear header extension plate 1 foot.	TRE611TN296	1.50	97.50	236.25	333.75	
288	TOP RAIL	Extension plate	Replace	Replace top front/rear header extension plate 8 ft.	TRE411REP107	5.00	325.			